

Instrucciones



Selection Programas



- 1 x = A₀ valor 1
- 2 x = A₀ valor 2
- 3 x = A₀ valor 3

Operacion

*) secado

Mal funcionamiento











de ahorro



intensivo



*) Optio



 **DISCHER Technik GmbH**
Fuhr 4-6 • D- 42781 Haan
Tel: +49 (0) 2104 2336 0
Fax: +49 (0) 2104 2336 99
info@discher.de
www.discher.de



Art.-Nr.: 14577-0625-PICCOLO-ESP