



KORT BRUKSANVISNING

DISCHER®

Programval



1 x = A₀ value 1

2 x = A₀ value 2

3 x = A₀ value 3

I Drift
*) Torkning
Störning



optional

Ekonomiprogram

Power- Program



 **DISCHER Technik GmbH**
Fuhr 4-6 • D- 42781 Haan
Tel: +49 (0) 2104 2336 0
Fax: +49 (0) 2104 2336 99
info@discher.de
www.discher.de

