

Trumpos naudojimo instrukcijos



Programos pasirinkim:




- 1 x = A₀ value 1
- 2 x = A₀ value 2
- 3 x = A₀ value 3

Irenginys veikia

*) Džiovinimas






Gedimas



Anteles

Basonai

*) opcija



 **DISCHER Technik GmbH**
Fuhr 4-6 • D- 42781 Haan
Tel: +49 (0) 2104 2336 0
Fax: +49 (0) 2104 2336 99
info@discher.de
www.discher.de

