






Trumpos naudojimo instrukcijos



1 x = A_0 value 1
2 x = A_0 value 2
3 x = A_0 value 3



 **DISCHER Technik GmbH**
Fuhr 4-6 • D- 42781 Haan
Tel: +49 (0) 2104 2336 0
Fax: +49 (0) 2104 2336 99
info@discher.de
www.discher.de

